

VPA-SPAN-(X) Installation



1
Remove Plastic Grommets from Front & Rear Cable Managers



2
Hook VPA-SPAN into the Round Hole of the Front & Rear Cable Manager



3
VPA-SPAN Adjusts to fill the gap between the Front & Rear Cable Managers

VPA-SPAN-(X) Installation

Comply with the following for safe installations:

- A. Use caution when installing or modifying telecommunications circuits.
- B. Never touch uninsulated wire terminals unless the circuit has been disconnected.
- C. Never install this device in a wet location.
- D. Never install wiring during a lightning storm.



Global Headquarters
Watertown, Connecticut USA
Tel: (1) 866-548-5814



www.siemon.com

For a complete listing of our global offices visit our web site