


VPC Installation Instructions



Parts Description



QTY DESCRIPTION

- 1 Vertical manager
- 1 Door assembly
- 2 Door Stop Brackets
- 8 10-24 X 3/8" Phillip Screws
- 12 3/8-16x1 screws
- 12 3/8-16 hex nuts
- 12 3/8 lock washers

* A 9/16-inch socket wrench or equivalent is required.


Required Tools

- 9/16 in. Socket Wrench
- Phillips Head Screwdriver




1

Using a phillips head screwdriver, attach door stop brackets to vertical manager using (4) 10-24 X 3/8" screws per bracket.



2


Some components may be attached to packing material. Verify the vertical manager is orientated correctly by ensuring the arrow found on the center plate is pointing up.



3


Line up the mounting holes on the rack and manager. The smaller diameter mounting holes will be used for Siemon racks. For all other racks, cross-reference the mounting-hole locations on the rack channels and the VPC. Using the hardware provided, secure all hardware with a 9/16-inch socket wrench or equivalent. Repeat these steps to mount the VPC between two racks.

VPC Installation Instructions



4 Install the (6) channel retainers on rear of the manager.

Note: Managers fit loosely for easy hinging. To secure managers, squeeze sides and slide down into locking position.



5 To install the door, place the bottom door pins into their respective holes on the bottom door ramp. Once the bottom pins are engaged push the top of the door into position. Move the top of the door slightly to ensure it is fully engaged.

To assist safe installations, comply with the following:

- A. Use caution when installing or modifying telecommunications circuits.
- B. Never touch uninsulated wire terminals unless the circuit has been disconnected.
- C. Never install this device in a wet location.
- D. Never install wiring during a lightning storm.



Siemon — Australia

Sydney, Australia
Tel: (61) 2 9452 2666

Siemon — CASA Central & South America

Bogota, Columbia
Tel: (011) 571 317 2121

Siemon — China

Beijing, P.R. China
Tel: (86) 10 6559 8860

Siemon — France

Paris, France
Tel: (33) 1 46 46 11 85

Siemon — Germany

Frankfurt, Germany
Tel: (49) (0) 69 97168 184

Siemon — Italy

Milano, Italy
Tel: (39) 02 64 672 209

Siemon — Japan

Tokyo, Japan
Tel: (03) 5437 1580

Siemon — Southeast Asia

Singapore
Tel: (65) 345 9119

Siemon — UK

Surrey, England
Tel: (44) (0) 1932 571771

Siemon — North America

Watertown, Connecticut
Tel: (1) 866-548-5814



www.siemon.com