


ULTRAsleeve® Instructions




The ULTRAsleeve® is a no heat protection cover for applying to the fused fiber joint after the fusion process.



1 Prepare the ULTRAsleeve® by removing and discarding the white protective strip.

Note: Ensure the factory adjusted opening is maintained.




2 Utilizing the optional ULTRAsleeve® closing tool* (p/n: FSCT1), place the ULTRAsleeve® into the tool with the opening facing up as shown.

*The ULTRAsleeve® may also be installed by hand. The closing tool is not required but does make for quicker, easier, and more accurate installations.



3 Place the fused fiber(s) into the center of the ULTRAsleeve® (in the opening). The foam holders on each side of the tool allow for about one pound retention. Fiber should be placed close to the bottom of the foam.



4 Gently close the two halves of the ULTRAsleeve® until the locking tabs snap into place. *When using the tool, simply turn the handle to the left or right.

ULTRAsleeve® Instructions

WARNING:

Optical transmitters and fiber optic test equipment used in the telecommunications industry uses invisible infrared energy. At sufficient power, this may cause eye or skin damage.

If you work with fiber optic products, including test equipment, consider the following:

1. Do not look into fibers or connectors. They may be 'live'.
2. Know what is happening with the fiber under test at the far end!
3. When connecting a light source, try to make it the last element you connect!
4. Whenever possible, switch off and disconnect your light source(s) before breaking any fiber connections.
5. Always consider the hazard to other people:
 - a. Use warning signs, etc.
 - b. Keep caps on unconnected fibers whenever possible.
 - c. If using "live" optical beams, keep them low and facing away from personnel.
6. Don't view optical outputs with a microscope, use a TV camera/monitor.
7. Elect a safety officer to:
 - a. Train staff
 - b. Maintain records of equipment classification, calibrations and safety checks.
8. Be careful of cut fibers. Remember they are sharp and difficult to see!

To assist safe installations, comply with the following:

- A. Use caution when installing or modifying telecommunications circuits.
- B. Never touch uninsulated wire terminals unless the circuit has been disconnected.
- C. Never install this device in a wet location.
- D. Never install wiring during a lightning storm.

Siemon — Australia

Sydney, Australia
Tel: (61) 2 9452 2666

Siemon — Canada

Markham, Ontario
Tel: (1) 905 940 9223

Siemon — China

Beijing, P.R. China
Tel: (86) 10 6559 8860

Siemon — France

Paris, France
Tel: (33) 1 46 46 11 85

Siemon — Germany

Frankfurt, Germany
Tel: (49) (0) 69 97168 184

Siemon — Italy

Milano, Italy
Tel: (39) 02 64 672 209

Siemon — Latin America

Coral Gables, Florida USA
Tel: (1) 305 446 9150

Latin American Sales Manufacturer's Reps

Castroville, Texas USA
Tel: (1) 830 538 6375

Siemon — Southeast Asia

Singapore
Tel: (65) 345 9119

Siemon — UK

Woking, England
Tel: (44) (0) 1483 480040

Siemon — USA

Watertown, Connecticut
Tel: (1) 866-548-5814



SIEMON™

www.siemon.com